




NOTES:

1. COORDINATE BREAK POINT OF SLOPE WITH POSSIBLE LOCATIONS OF AUXILIARY RAILS IN TRENCH RUN.
2. ADD OR REMOVE EPS FOAM AT END OF SECTIONS AT SLOPE BREAK AS REQUIRED.



REV	DESCRIPTION	BY	CHKD	DATE
-----	-------------	----	------	------

 <p>P.O. BOX 837 / 259 MURDOCK ROAD TROUTMAN, NC 28166 (704) 528-9806 (800) 438-6057 www.abtdrains.com</p>	DETAIL DRAWING © 2008 ABT, Inc. TRENCH FORMER DETAILS SLOPE BREAK ASSEMBLY		
	FILE:	DET-G3-SLOPE-00	PART:

Proprietary rights of ABT, Inc. are included in the information disclosed herein. The recipient, by accepting this document, agrees that neither this document nor the information disclosed herein nor any part thereof shall be copied, reproduced or transferred to others for manufacturing or for any other purpose except as specifically authorized in writing by ABT, Inc.

DISCLAIMER: The customer and the customer's architects, engineers, consultants and other professionals are completely responsible for the selection, installation, and maintenance of any product purchased from ABT, and EXCEPT AS EXPRESSLY PROVIDED IN ABT'S STANDARD WARRANTIES, ABT MAKES NO WARRANTY, EXPRESS OR IMPLIED, AS TO THE SUITABILITY, DESIGN, MERCHANTABILITY, OR FITNESS OF THE PRODUCT FOR THE CUSTOMER'S APPLICATION. Copies of ABT's standard warranties are available upon request.